

MODEL**ORDER CODE**

ThermaGuard - 101	226-511
ThermaGuard - 102	226-512
ThermaGuard Vaccine Kit	891-912

SPECIFICATIONS

Internal Range	-4 to 122°F (-20 to 50°C)
Probe Range	-40 to 122°F (-40 to 50°C)
Accuracy	±0.7°F (±0.4°C)
Display Update	1 second
Probe	Thermistor
Resolution	0.1°
Units	°C/°F switchable
Water Resistance	IP54
Battery	2 x 1.5 volt AA, 25,000 hours continuous use, 3 years typical
Operating Range	-4 to 122°F (-20 to 50°C)
Display	1.85 H x 1.85 W inches (47 H x 47 W mm)
Dimensions	3.77 H x 2.85 W x 1.14 D inches
Weight	(96 H x 72.5 W x 29 D mm)
Certificate	5.8oz. (165g) Includes calibration certificate

**ThermoWorks****ThermaGuard
Fridge/Freezer
Thermometers****ACCESSORIES/RELATED ITEMS**

Spare Bracket/Stand
(THS-400-8590)



Flexible Tripod
(TW-3201X)



**Duracell Procell AA
Battery, 4-pack**
(PC1500)



Mounting Magnet
(THS-830-800)

For warranty, service, and technical assistance,
please contact ThermoWorks' Technical Support at (801)
756-7705 or email at techsupport@thermoworks.com.

**ThermoWorks**

ThermoWorks, Inc.
Utah, U.S.A.

Ph: 801-756-7705 Fax: 801-756-8948
www.thermoworks.com

Made in the UK

**Operating Instructions**

INSTRUMENT OPERATION - The instrument continuously displays and measures temperature. ThermoGuard incorporates fixed internal/external sealed thermistors for slow-moving, high accuracy applications.

The normal display for the instrument is to show the probe temperature and the MIN/MAX readings for the selected probe.

FAULTY PROBE - If the probe has developed an 'Open Circuit' fault the instrument will display 'Err'.

SENSORS - The LCD displays one sensor at a time. When in normal display, press MODE to alternate between sensors. Sensor 1 is the upper probe (or internal Sensor) and Sensor 2 is the lower probe, as noted on the rear label. If the measured temperature exceeds the instruments temperature range 'Err' will be displayed.

°C/°F - When in normal display press and hold the SET button for 5 seconds to change between °C and °F.

MIN/MAX - The MIN/MAX temperatures are displayed in the lower sections of the LCD. Press and hold MODE for 3 seconds to reset the readings for the selected probe, 'rSt' will be displayed. The MIN/MAX readings are not retained when the batteries are replaced.

SETTING ALARMS - Press ALARM to display the Lo/Hi alarm levels, hold SET for 3 seconds to enter alarm set-up. 'SET' will be displayed with 'Lo' flashing. Use the Up/Down arrows to adjust the alarm, then press SET to save. Repeat the steps to set-up 'Hi' alarm. Press SET to save and exit alarm set-up. To set the alarm levels for the other sensor, change the displayed sensor and repeat the alarm set-up procedure.

ALARMS - Press ALARM and the Lo/Hi alarm levels will be displayed instead of MIN/MAX. Press ALARM again to return, alternatively it will return back to normal display after 10 seconds.

If an alarm is triggered, the alarm and the alarm symbol will flash, as well as an audible alarm, unless muted.

Press any button to silence the alarm; the LCD will continue to flash until it comes out of alarm.

ALARM VOLUME - When in normal display press and hold ALARM for 5 seconds to mute/un-mute the alarm volume. The alarm symbol and ON/OFF will be displayed.

CALCHECK - To check the accuracy of the thermometers electronics, while in normal display press and hold the ALARM & SET buttons for 3 seconds, the unit will display 32°F.

BATTERY REPLACEMENT - The instrument displays a battery symbol which will warn you of half and low battery, at which point the batteries should be changed.

You will require a flat-headed screwdriver. Place the instrument display-down on a solid surface, unscrew and remove the battery cover on the rear of the instrument. Remove batteries, disposing of them appropriately. Fit 2x AA batteries, noting the polarities marked on the plastic. Replace the battery cover and tighten the screw, do not use excessive force. The instrument will then start automatically.

WARNING - IPA and other solvents may cause damage to the case and screen of this instrument.

GUARANTEE - This instrument carries a two-year warranty against defects in either components or workmanship. During this period, products that prove to be defective will, at the discretion of ThermoWorks, be either repaired or replaced without charge. This warranty does not apply to probes, where a six-month period is offered. Full details of liability are available within ThermoWorks' Terms & Conditions of Sale at www.thermoworks.com/product-warranty.