

Extra Big & Loud Timer

Operating Instructions

Adjustable Alarm Volume

Press VOL to select the desired alarm volume from 1 to 4.

Set the Timer

Values on the timer are displayed in the hr:min:sec format.

With reference to the following examples, set the desired countdown times.

Press STOP/CLEAR to clear the display before setting new values

To set 12 seconds = press 1, 2

To set 12 minutes = press 1,2,0,0

To set 12 hours = press 1,2,0,0,0,0

To set 12 hours, 12 minutes = press 1,2,1,2,0,0

To set 12 hours, 12 minutes, 12 seconds = press 1,2,1,2,1,2

Start the Countdown Timer

Press START/MEMO to begin the countdown.

When the timer reaches 00:00:00, the alarm will sound.

The timer will start to count up showing the elapsed time since the alarm has sounded.

Press any button to stop the alarm.

Memory

The timer will retain the last value entered in memory. The value is kept until replaced by another value.

Press START/MEMO to recall the value.

Press STOP/CLEAR to clear the display. This does not erase the value from memory.

Battery Installation

Replace the battery when the low battery symbol appears.

1. Remove the screw on the battery cover on the back of the timer.
2. Remove the cover, being careful not to dislodge the rubber gasket.
3. Replace the batteries in the cover with one 9 volt battery.
4. Replace the gasket and cover, and secure the screw.

Care and Cleaning

If the timer will not be used for an extended period of time, remove the batteries to prevent battery leakage.

Be sure the battery cover and gasket are tightened securely after replacing the battery, otherwise the timer's water resistance may be affected.

Do not expose to temperatures over 104°F (40°C).

Not submersible.

Specifications

Countdown Range 99 hours 59 minutes 59 seconds

Countup Range 99 hours 59 minutes 59 seconds

Display Resolution 1 second

Alarm Sound Volume 110 db at 11.8 inches (300mm)

Alarm Volume Control Adjustable in 4 steps

Water Resistance IP65

Battery 9V x 1 piece

Display Size 0.9 H x 2.5 W inches (22 H x 65 W mm)

Product Size 5.1 H x 3.5 W x 1.1 D inches (129 H x 90 W x 28 D mm)

Operating Temperature 32 to 104°F (0 to 40°C)



ThermoWorks

For service or warranty:

www.thermoworks.com
1762 W. 20 S. #100
Lindon, UT 84042

Questions?

techsupport@thermoworks.com
1-800-393-6434

P-11-037-02-a