

# RT101A Low Cost Timer

## Battery Installation

Replace battery if the LCD display becomes dim.

1. Remove the battery cover.
2. Install the battery observing the correct polarity.
3. Replace the battery cover.

## Instrument Operation

### Count down Timer

1. Press the MIN and SEC buttons together to clear the display.
2. Press the MIN or SEC button to set the desired count down time.
3. Press the START/STOP button to start the timer. When the display reaches 00m00s the alarm will sound and the timer will begin counting up to indicate the elapsed time.
4. Press the START/STOP button to stop the timer and silence the alarm. The timer display will revert back to the last set count down time.

### Count up Timer

1. Press the MIN and SEC buttons together to clear the display.
2. Press the START/STOP button to start the timer counting up.
3. Press the START/STOP button to stop the timer.
4. If the timer reaches its maximum range the display will stop counting and continue flashing. Press START/STOP to reset.

## Care

Remove the battery to avoid leakage if the timer will not be used for an extended period of time. Avoid contact with water.

## Specifications

<b>Range</b>	99 minutes 59 seconds
<b>Display Resolution</b>	1 second
<b>Display Size</b>	1.85 (W) x 0.78 (H) inches / 47 (W) x 20 (H) mm
<b>Digit Size</b>	0.33 (W) x 0.7 (H) inches / 4 (W) x 10 (H) mm
<b>Battery</b>	1.5 volt, size AAA x 1
<b>Product Size</b>	2.5 (W) x 2.5 (H) x 0.6 (D) inches / 63 (W) x 63 (H) x 15 (D) mm



**ThermoWorks**

Lindon, Utah  
Ph: 801-756-7705  
Fax: 801-756-8948  
[www.thermoworks.com](http://www.thermoworks.com)



RT101A Low Cost Timer



Made in China