

# ThermoDrop™






## Operating Instructions

---

### **What's included:**

ThermoDrop, battery, split ring, and this instruction card.

### **How to operate:**

- To power on ThermoDrop, press  once.
- To activate backlight, press . Backlight stays on for 10 seconds.
- To power off ThermoDrop, press and hold  for 5 seconds.
- To view Max/Min readings, press and hold  for 3 seconds. MAX will flash in the display, press again to view Min reading. MIN will flash in the display.
- To switch from °F to °C, press and hold  for 5 seconds upon start up.

### **To Change Battery:**

- Replace with 3-volt, CR2025 button cell battery. Use a coin to open the battery cover on the back. Install the battery according to the correct polarity.

For service or warranty:  
1-801-756-7705 • 1-800-393-6434  
[techsupport@thermoworks.com](mailto:techsupport@thermoworks.com)

# Important Ambient Temperatures Guide

---

## **Fridge Temp Range**

33 to 40°F

## **Freezer Temp Range**

-2 to 32°F

## **Hottest Recorded Temp**

134.1°F Death Valley, CA / July 1913

## **Coldest Recorded Temp**

-128.6°F Antarctica / July 1983

## **Frostbite Risk**

0°F with 15 mph wind = 30 min

-10°F with 5 mph wind = 30 min

## **Man Cave**

60 to 65°F

## **Normal Room Temp**

65 to 75°F

## **Grandma's House**

75 to 85°F



**ThermoWorks**