

This Quick-Start guide covers preparation, use and maintenance to assist you in getting the best results from your LogTag[®].

Products

LogTag® Recorders offer a variety of different models. The product range is constantly being updated and new models added, so visit www.thermoworks.com/products/logger/logtag.html

to get the latest information and news about upcoming product releases.

You can find a list of the most common models in table 1. Using the LogTag® most appropriate to your measuring and monitoring task will ensure the best results.

LogTag® recorder products have a number of features in common: a green OK LED, a red ALERT LED, a START/ MARK button and a mounting lug.



GETTING STARTED

All you need to use the LogTag® recording system are a LogTag® interface, a PC running Windows XP or later, the LogTag® Analyzer PC application and the LogTag® recorder itself. Don't plug the interface into the computer just yet, this will be done at the conclusion of the software installation.

SOFTWARE INSTALLATION

Greek.

Before using a LogTag® recorder you will need to download the LogTag® Analyzer software from LogTag's web site at www.thermoworks.com/software/. After registering you will be e-mailed with a link, from where you can download the latest version, which supports multiple languages, including those with special characters such as Chinese or

Once downloaded, start the executable to initiate the installation process; please note you will need local administrator rights to do

Wait until finished before installing your interface.

INTERFACE INSTALLATION

After the installation is complete, you will see a new icon on your desktop. You can now plug your interface into a USB port, or an RS232 port if you were supplied this type of interface. For USB interfaces the drivers will now install automatically. Your operating system will notify you once the driver installation has succeeded. You can use multiple interfaces on one computer and also mix RS232 and USB interfaces.

When all interfaces are installed you are ready to proceed.

CONFIGURING A LOGTAG

You will need to configure a LogTag® if you want to take readings with it. Insert the LogTag® into the interface, contacts in first and the LED's towards the interface label as shown in the picture on the right.


Start the software. The easiest way to configure the LogTag® for a trip is the use of the LogTag® Wizard by clicking on the Wizard toolbar button or selecting LogTag-Wizard from the menu.

Product Type	Integrated Temperature Sensor	Integrated Humidity Sensor	Sensor Probe	Display	Recording Temperature Range	Memory
TRIX-8	•				-40°C to 85°C	8,000 samples
TRIX-16	•				-40°C to 85°C	16,000 samples
HAXO-8	•	•			-40°C to 85°C	8,000 samples
SRIC-4	•				-20°C to 65°C	4,000 samples
TREX-8			•		-40°C to 99°C	8,000 samples
TRIL-8	•				-80°C to 40°C	8,000 samples
TREL-8			•		-80°C to 40°C	8,000 samples
SRIL-8	•				-80°C to 40°C	8,000 samples
TRID30-7	•			•	-30°C to 60°C	7770 samples
TRED30-7			•	•	-40°C to 99°C	7770 samples

Table 1: LogTag Logger Models

The Wizard will

- Query all interfaces and any recorders inside them
- Download any data from recorders found and save them to files
- Allow you to enter parameters for a new trip, like shown in this



• Upload the new configuration to the recorders

You can enter parameters such as start method (push button or date/ time), logging interval (30 seconds to 18 hours), logging duration, start delay, access passwords and not to forget Alert values, which are used for the Alert LED activation and the reporting functions in LogTag® Analyzer, and also add a description about your trip.

ANALYSING THE RESULTS

Once loggers have completed a trip, you can use the LogTag® Analyzer software to analyse and archive the data, to export them to other programs such as MS Excel or to e-mail them and upload them to an off-site server.

A number of controls and displays assist you in operating the software.

- Menu
- Toolbars
- Data window with graph, list, summary and averaging tabs
- Multichart windows and annotations for adding notes
- Context menus allowing quick access to the most used functions.

For a full list of features please see the LogTag* Analyzer User Guide, which can be accessed through the Help Menu. You can also call up on-line help information for all windows and dialogue buttons by pressing the F1 key.

LOGTAG INDICATOR LEDS

The LogTag® recorder itself can give you important status information by flashing its indicator LEDs in different patterns. Both the red 'Alert' LED and the green 'OK' LED convey information about configuration and trip parameters, Alert status and give feedback when users interact with the START/MARK button.

You will find a summary of the LED patterns with a description about their meaning in table 2 on the right.

START/MARK BUTTON

Once a LogTag* has been configured, pressing the START/MARK button has a different outcome depending on what

the recorder is doing at the time the button is pressed.

- If the recorder is configured for a push button start, pressing this button will activate the main recording. There is no need to be concerned about any lost data if the user forgets to press this button, as a pre-start recording feature can be activated, logging data even before the trip is started.
- Once the LogTag® has been started, pressing the button will insert an inspection mark in the data recordings, which is displayed when viewing the data in the software.
- If configured, Alert Conditions can be reset when this button is pressed.

CUSTOMILING THE SOFTWARE

The software allows you to customize many of the features to your individual requirements. Not only can you change some of the more basic options like display language and temperature units, but also adapt some of the more advanced parameters for e-mail and FTP functions, storage folder location, file name and frequency for automatic software updates.

GETTING THE RIGHT **R**ESULTS

When you use the LogTag® units, please take a moment to consider the application and how

to best approach the monitoring task. Allow the units to be located in a place with good air movement, make sure HAXO units are not lying flat so water and dust cannot gather around the sensor filter and provide adequate insulation around access holes for sensors with probes.

CERTIFICATIONS

LogTag* has achieved certification with a number of Authorities, demonstrating the quality and suitability of the LogTag* Recorders for applications where accuracy and consistency is required. Such certifications have - amongst others- been issued by such organisations as the FCC, CE, C-TICK, TÜV and the WHO.

FDA TITLE 21 CFR 11

Compliance to the FDA requirements is available to users via a special server utility, available on request, which can log events and be used to digitally sign data files.

Signal Sequence **Occurrence** Sequence of four displayed after configuration has been successfully applied to the LogTag® LogTag® wake-up alternate flashes of signal when a LogTag® is woken up from hibernation state green-red LED's Not to be mixed up with... LogTag® start-up Sequence of sixteen displayed when the LogTag® starts its recording cycle alternate flashes of signal green-red LED's Mark signal displayed when pressing start/mark button while recording to indicate an inspection Sequence of five simultaneous flashes of mark in the software green and red LED's displayed directly after the start-up signal following a push button start where a recording delay has been configured. In this instance the start-up signal is repeated when the actual recording begins Single flash of green Logging active, no indicates LogTag® is recording alert present LED every 4 seconds This is not displayed when pre-start is active and the main logging cycle has not (approx.) yet started. It is also not displayed when the green LED has been turned off in the configuration screen Logging finished, Single flash of green indicates LogTag® has finished recording no alert present LED every 8 seconds This is not displayed when the green LED has been turned off in the configuration (approx.) screen. Will also be displayed when unit has been woken up from hibernation Alert condition Single flash of red displayed when the LogTag® has detected an alert condition and the Alert LED has LED every 4 seconds present been activated If an alert is present you cannot determine if the unit is still logging or has finished its log cycle. If the Alert LED has not been activated during configuration, in essence the visual indicators have been disabled, and the green LED will flash every 4 or 8 seconds as above. The green LED will during communication with the interface the green LED will flash occasionally; no Communication flash occasionally information is conveyed in this Start button press red LED glows faintly This is by design but conveys no information

Table 2: Light Patterns

MAINTENANCE

LogTag* recorder products are rugged and need little maintenance, it does pay however to observe some basic rules when handling the recorders to maximize their use.

BATTERY REPLACEMENT

Most LogTag® recorder products have a replaceable battery, some of which may be soldered to the electronics to avoid contact issues that exist with other branded loggers; for these you will need some soldering expertise and a battery replacement kit from your distributor. Please also note that the products do contain a non-rechargeable Lithium Battery, which must be disposed of in accordance with local regulations.

HIBERNATION

To prolong the life of your recorder you can hibernate it between trips via LogTag* Analyzer when it is not being used for extended periods. Please refer to the User Guide in the section about 'Hibernation'

CALIBRATIO

All LogTag® recorders can be calibrated with special utility software, which will be made available to calibration labs upon request. Re-calibrated loggers can be identified and traced back to the calibrating lab thus reducing the risk of fraudulent data tampering.

BASIC TROUBLESHOOTING

WATER INGRESS

Please carefully observe the IP rating for your unit and remember that none of the LogTag* products can be immersed into liquids.

CONTACT CLEANING

Keep the three metal contacts at the back of the recorder clean and free from tape residue, dirt or other contaminants, as these usually result in communications problems. If required, clean them with a soft pencil eraser, but don't use abrasive materials as you may permanently damage them.

GETTING HELP

If after studying the User Guide you still need further information, please visit the Support section of the LogTag* Recorders website.

THANK YOU...

...for choosing LogTag® Recorders, we are looking forward to working with you!