ThermoWorks WAND™
Quick Reference

**Measuring Forehead Temperatures
Quick, Easy, and Reliable!**

1 **Power on device**

2 **Point at center of
forehead 1–2 inches
away**

3 **Press and hold START for 1 second—
a single beep tells you it's done**

WAND is pre-set to forehead mode and to display temperature in
Fahrenheit. Three short beeps followed by one long beep while taking a
forehead reading means that the temperature exceeded 99.5°F (37.5°C).
Please wait 2 seconds between measurements.

ThermoWorks

Functions

Power Off Device – Device will auto-off after 60 seconds to save battery life. Or, press and hold Power button for about 5 seconds. 'Off' will flash before powering off.

View Readings – With device turned on, press Power button momentarily to see the last reading, which is reading number 1. Each subsequent press of the Power button will show up to 25 readings in order. The reading number will flash before displaying the value.

Mute – With device turned on, press and hold Power button for 3 seconds until speaker icon flashes, then release. Repeat steps to unmute.

Change to Surface Mode – With device turned on, press and hold Power button, then press Start to toggle between modes. Device will automatically return to forehead mode after powered off and back on again.

Change from °F to °C – Default unit is °F. With device turned off, press and hold Start and the Power button simultaneously for three seconds. Units will change.

Cautions

- Forehead should be clean, dry, and unobstructed before taking readings.
- WAND is not waterproof. Avoid wet areas and splashes.
- Do not expose device to temperatures above 100°F (38°C) or below 50°F (10°C).
- Replace batteries when battery icon flashes.
- Store device at room temperature where readings will be taken for best results.
- Avoid drops, bumps, and rough handling that could damage device.
- Sensor lens area is the most delicate part; keep clean and free from debris.
- Consult user manual before cleaning lens.